POLYURETHANE COATING FOR THE EXTERIOR OF WOODEN SUBSTRATES

1. LAYER
2. MATERIALS
3. EQUIPMENT
4. PREPARATION
5. APPLICATION
6. THICKNESS

Nanjing Skybamboo Science & Technology Industry Co., Ltd. China
www.skybamboo.com

Improves Polyurethane Adhesion to the Wood



















Hollowood joint glue
1st step:brushing ivory-white latex
2nd step:glue reinforcement
3rd step:fix with nail

NOTES:
1. Material: 15mm ,12mm Russian plywood
2. Adhesive : Nanjing Skybamboo Science & Technology Industry Co.,Ltd.,China SA-100 adhesive
3. Brace angle : must meet the brace angle inspection standard (refer relative standard)
4. Rigging insert: must meet the rigging insert inspection standard (refer relative standard)
5. Structure :
   1) It should be T-groove connection between board and board (refer relative drawings for shape and size details)
   2) Judgement of adhesive intensity is based on wood broken ratio. Ensure the wood broken ratio≥70%
   3) Position, quantity and space of glue spreading and nails must meet the requirement of relative drawings.
6. Geometry:
   1) Geometry precision must meet the drawing requirement (refer drawing for details)
   2) Add diagonal inspection to ensure the cabinet structure. The difference between two diagonal should be≤2.5mm.
7. Finish:
   1) color 2) veins 3) shining refer samples
   4) adhesion ability inspection
8. Key points :
   1) Counter sink of rigging screw: diameter Φ30.5-0.2, depth 5.5+0.3
   2) Match of grille and cabinet: vertical≤0.2mm, horizontal -0.5mm, depth -0.3mm
   3) In the place of compression driver plate mounting (refer attached drawing A), there should be no dent, ridge, glue or paint dot.
   4) In the place of Vcc-2 assembly mounting area (refer attached drawing B), there should be no dent, ridge, paint or calcium carbonate dot.
   5) Two holes of bass Vcc-2 assembly should be symmetrical to the cabinet centre, tolerance≤0.5mm.
   6) Mounting hole for the rear cover of compression driver should be counter sink, with depth 5.5±0.3mm. The bottom should be flat, no protrudent dot.
   7) Clear up all fibers before glue spreading and cabinet final assembly. Ensure that there's no fiber in the T-groove connection gap.
   8) If there's radiation angle in the joint of horn and cabinet, ensure the consistency of each line direction and symmetry of relative line.
      If it's 0°angle in the joint, make sure the line is clear.
   9) Clear up all surfaces and spread a.B glue on the thread line before fixing rigging screws into brace angle.
   10) Fill the logo groove.

NOTES?
1.15mm ,12mm Russian plywood
2.Lamination of two veneers border upon should be vertical
3.Both side symmetrical veneers of the center veneer are from the same or similar type wood
4.Degree of moisture 6-14%
5.Glue:SA-100;(Nanjing Skybamboo Science & Technology Industry Co.,Ltd.China)BOSE Part No:PT280640

Bonding Properties of Gluts		
Impregnation delamination,%	<10	
Compressive shear strength	strength(MPa)	wood failure(%)
Manchurian ash (hard wood)	>=10	>=60
Spruse (soft wood)	>=6	>=65

a.peeling off rate after dipping in test % ?10
b.peeling off rate after terv. % ?10
6.CHEMTHANE 7030 polyurethane protective coating for wood.
7.CHENMTHANE 1400 aliphatic water-based coating

REVISIONS				
REV	DESCRIPTION	CHK	ENG	DATE

Unless otherwise specified dimensions are in millimeter. Tolerances are:
Decimals Angles
X. +/-1.2 +/-
.X +/- 0.5
.XX+/-

THIRD ANGLE PROJECTION

MATERIAL: See Notes

FINISH: See Notes

LEVEL 3 2 1

DRAFTER
CHECKER
ENGINEER
APP'D BY

DATE: 06/01/06 06/01/06

ELDER AUDIO MANUFACTORY
No.Third Industrial District, Yinlang Dongguan Guangdong 523121 China.

DESCRIPTION: CABINET LL3292-WP

SIZE	FSCM	CLASS	DWG NO.:	REV
C			EF-XIEGLN-146674	

SCALE: NONE SHEET 1 of 1

FNAME REVDATE USER